- [6] Bellcore Technical Reference, TR-EOP-000242, Issue 1, May 1985, Network Interface for Non-registered Voice-band Analog Private Line Services.
- [7] Bellcore Technical Reference, TR-NPL-000334, Issue 1, June 1986, Revision 1, November 1987, Voice Grade Switched Access Service Transmission Parameter Limits and Interface Combinations.
- [8] Bellcore Technical Reference, TR-NPL-000335, Issue 1, June 1986, Revision 1, February 1987, Revision 2, November 1988, Voice Grade Special Access Service Transmission Parameter Limits and Interface Combinations.
- [9] Bellcore Technical Reference, TR-NPL-000336, Issue 1, October 1987, Metallic and Telegraph Grade Special Access Service Transmission Parameter Limits and Interface Combinations.
- [10] Bellcore Technical Reference, TR-NPL-000337, Issue 1, July 1987, Program Audio Special Access and Local Channel Services
- [11] Bellcore Technical Reference, TR-NPL-000338, Issue 1 December, 1986, Television Special Access and Local Channel Services - Transmission Parameter Limits and Interface Combinations.
- [12] Bellcore Technical Reference, TR-NPL-000339, Issue 1, October 1987, Wideband Analog Special Access Service Transmission Parameter Limits and Interface Combinations.
- [13] Bellcore Technical Reference, TR-NPL-000340, Issue 1, October 1987, Wideband Data Special Access Service Transmission Parameter Limits and Interface Combinations.
- [14] Bellcore Technical Reference, TR-NPL-000341, Issue 1, March 1989, Digital Data Special Access Service Transmission Parameter Limits and Interface Combinations.
- [15] EIA/TIA Standard, EIA/TIA 570, June 1991, Residential and Light Commercial Telecommunications Wiring Standard.
- [16] EIA/TIA Standard, EIA/TIA 568, July 1991, Commercial Building Telecommunications Wiring Standard.
- [17] Bellcore Special Report, SR-STS-000307, Issue 2, December, 1990, Industry Support Interface (ISI): NC/NCI Code Dictionary.
- [18] Bellcore Technical Reference, TR-EOP-000242, Issue 1, May 1985, Network Interface for Nonregistered Voice-Band Analog Private Line Services.

- [19] ANSI T1.408-1990, Integrated Services Digital Network Primary Rate Customer Installation Metallic Interface Layer 1 Specification.
- [20] ANSI T1.409-1991, Interface between Carriers and Customer Installations Analog Voicegrade Special Access Lines Using E&M Signaling.
- [21] ANSI T1.605-1991, Integrated Services Digital Network (ISDN) Basic Access Interface From S and T Reference Points (Layer 1 Specification).

2.2 Sources

[1] FCC Documents:

Government Printing Office Washington DC 20402 (202) 783-3238

[2] American National Standards:

The American National Standards Institute
11 West 42nd Street
New York, NY 10036
(212) 642-4900

[3] Bellcore Technical References:

Bell Communications Research 60 New England Ave Piscataway, NJ 08854-4196 1(800) 521-2673

- [4] Telecommunications Industry Assn./Electronics Industries Assn.:
 Global Engineering Documents
 1990 M Street, NW
 Washington, DC 20036
 1(800) 854-7179
- [5] Committee T1 Technical Reports
 T1 Secretariat
 Exchange Carrier Standards Association
 1200 G Street, N.W.
 Washington, DC 20005
 (202) 434-8845

3. GENERAL INFORMATION

This Technical Report is intended to be used as a reference for the selection of the appropriate connector wiring configuration at the Carrier to Customer Installation (CI) Interface and within the CI. The physical connector specifications are not included. Information on physical connector specifications can be obtained by referencing the applicable standard or regulation.

As new connector configurations are submitted, the committee will consider them for inclusion into the catalog. When new configurations are adopted, a revised Section index will be made available along with the new or revised configurations. Each configuration will be dated to insure proper identification.

3.1 Registration Connector Configurations

Registration connector configurations are those wiring configurations that have been adopted by the Federal Communications Commission (FCC) as standard connector configurations for connection of registered terminal equipment or systems to the telecommunications network. Connector configurations included under the FCC program are designated RJ---. This five character designation identifies the exact wiring configuration that will be provided by the carrier and customer at the network interface.

3.2 Standard Connector Configurations

Standard connector configurations are those configurations that have been adopted under an industry standard, but are not within the scope of the FCCs Registration Program. These connector configurations are designated by a five character code SJ---. This code designates the exact wiring configuration that will be provided by the carrier and customer at the network interface.

3.3 Other Connector Configurations

Other connector configurations include those configurations that are described in technical references or tariffs published by carriers. These connector configurations can be designated by a three or five character code at the discretion of the carrier. The code designates the configuration that a particular carrier provides. This code may not be the same for all carriers.

3.4 Customer Premises Connector Wiring Configurations

Customer premises connector wiring configurations are determined either by a standards forum or a manufacturer. Manufacturers have the freedom to develop a connector configuration independent of the RJxxx connectors for equipment to equipment or equipment to premises wiring connectors. Some manufacturers have developed

individual connector wiring configurations while others have used connector configurations that mirror the RJxxx designations.

3.5 Physical Specifications

The physical specifications for the connector configurations depicted in this technical report are covered by FCC regulations or other industry standards. The physical specifications for all connectors used in the FCCs Registration Program are outlined in Part 68 of the FCCs Rules and Regulations. Specifications for standard jacks or other connections can be found in either the associated technical reference or industry standard.

4. INTERFACE CODES

Interface Codes were established to facilitate ordering the proper transmission levels, signaling arrangements and electrical characteristics at the Carrier to Customer Installation Interface. Two distinct types of network interface codes have been standardized, Facility Interface Codes (FIC) and Network Channel Interface (NCI) codes. The format of both code types provide the means to specify the necessary parameters.

For the purpose of this document, no distinction is made regarding jurisdictional application by code type and both are listed under "Interface Codes" in this Section. The Tables are provided to assist in determining which connector configuration is usually associated with which interface. Tables 3,9,10,11 and 12 indicate the connector wiring configurations that are usually associated with the interface codes. Table 9 and 10 address non-switched analog and digital services. Table 11 and 12 address switched analog and digital services. Table 3 provides a matrix of the analog facility interface codes.

4.1 Facility Interface Codes

Facility Interface Codes were adopted to facilitate the ordering of certain analog private line services that had been included under Part 68 of the FCCs Rules and Regulations. With the adoption of Part 68 rules for digital services, the FCC expanded the FIC's. The new codes that were adopted, at the recommendation of the industry, were the NCI codes that had been developed for switched and special Access Services. In associated FCC documents these codes are listed as "Facility Interface Codes", somewhat blurring the distinction between the code types. Examples of the two FIC structures are given in Table 1. A translation guide for analog codes developed with a FIC structure is provided in Table 2. Table 3 provides cross-references to the FICs and the connectors. Translation guidelines for FIC codes structured as NCI codes are provided in Tables 4 thru 8.

4.2 Network Channel Interface Codes

NCI codes were developed in connection with the AT&T divestiture of the Bell Operating Companies and were originally intended to define interfaces connecting Local Exchange Carrier (LEC) facilities with Interexchange Carriers (IC) or End User (EU) customers of ICs for ordering of Access Services. Many NCI codes were developed that do suitable for Carrier interfaces Customer to interconnection. Therefore this report will not attempt to identify all possible NCI codes. Table 4 provides the structure of the NCI codes and Tables 5 and 6 provide a list of the Total Wires and the Impedance Codes options in the NCI structure. Table 7 provides an illustrative list of the NCI protocal codes that are used to define Carrier to Customer Installation interfaces ordered as access arrangements.

4.3 Technical Description Codes

An earlier interface code type, the Technical Description Codes (TDC), although still valid for connection of certain grandfathered equipment, will not be addressed in the wiring configurations of this Technical Report. (An example of a TDC for a tie trunk arrangement is 11TTMB.)

Table 1. Examples of Facility Interface Codes

Analog Facility Interface Codes - FIC Structure (See Table 2)

```
OL13A,B, or C Off Premises Stations
               Automatic Identification of Outward Dialing (AIOD)
AX15X
               Message Registration
MX13X
TL11M or E
              Tie Trunk
TL12M or E
              Tie Trunk
TL31M or E
               Tie Trunk
TL32M or E
               Tie Trunk
               Tie Trunk
TC31M or E
TC32M or E
               Tie Trunk
```

Analog Facility Interface Codes - NCI Structure (See Table 4)

| 02LR2 | 2-wire Private Line automatic ringdown |
|----------|--|
| 04LR2 | 4-wire Private Line automatic ringdown |
| 02AC2 | 2-wire Private Line manual ringdown: customer |
| | provided ringing |
| 04AC2 | 4-wire Private Line manual ringdown: customer |
| | provided ringing |
| 02NO2 | 2-wire Private Line no signaling conversion (Inband) |
| 02LS2 | 2-wire switched access loop start |
| 02GS2 | 2-wire switched access ground start |
| 04LS2 | 4-wire switched access loop start |
| 04GS2 | 4-wire switched access ground start |
| 02RV2-T | 2-wire switched access reverse battery customer |
| | terminates use for Direct Inward Dialing ports |
| 04RV2-T | 4-wire switched access reverse battery customer |
| | terminates use for Direct Inward Dialing ports |
| Metallic | |
| LADC | Local Area Data Channels |

Digital Facility Interface Codes - NCI Structure (See Table 4)

1.544 Mbps Service

| 04DU9-B | 1.544 Mbps Superframe format (SF) |
|----------|--|
| 04DU9-C | 1.544 Mbps Extended Superframe format (ESF) |
| 04DU9-S | 1.544 Mbps Extended Superframe format & B8ZS line code |
| 04DU9-Z- | 1.544 Mbps Extended Superframe format with ZBTSI |

Subrate Services

| 04DU5-24 | | | | interface |
|----------|-----|------|---------|-----------|
| 04DU5-48 | 4.8 | kbps | digital | interface |
| 04DU5-56 | 56 | kbps | digital | interface |
| 04DU5-96 | 9.6 | kbps | digital | interface |

Table 2. Analog Facility Interface Code Translation

First Character:

- A Automatic Identification of Outward Dialing
- M Message Registration
- O Off Premises Station
- T Tie Trunk

Second Character:

- C Conventional Term Set
- L Lossless Interface
- X Reserved

Third Character:

- 1 Type 1 Transmission Interface 2 wire
- 3 Type 3 Transmission Interface 4 wire

Fourth Character:

- 1 Type 1 E&M Interface
- 2 Type 2 E&M Interface
- 3 Loop Signaling Interface
- 4 Reserved
- 5 Simplex Signaling

Fifth Character:

- A Registered Class A OPS Port
- B Registered Class B OPS Port
- C Registered Class C OPS Port
- E Provides Ground on E Lead to Originate
- M Provides Battery on M Lead to Originate
- X Reserved

Example for Code TL31M:

- T = Tie Trunk
- L = Lossless Interface
- 3 = Type 3 Transmission Interface 4 wire
- 1 = Type 1 E&M Interface
- M = Provides Battery on M lead to Originate

Table 3: Analog Facility Interface Code (FIC) to Connector Matrix

| Jacks | | Analog Facility Interface Codes | | | | | | | | | | | |
|---------|----|---------------------------------|----|----|----|-----|-----|-----|-----|-----|-----|--|--|
| | 0 | 0 | 0 | A | M | T | T | T | T | T | T | | |
| | L | L | L | X | X | L | L | L | L | С | С | | |
| 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 3 | 3 | 3 | 3 | | |
| | 3 | 3 | 3 | 5 | 3 | 1 | 2 | 1 | 2 | 1 | 2 | | |
| | Α | В | C | X | X | M/E | M/E | M/E | M/E | M/E | M/E | | |
| RJ11C/W | 1 | 1 | 1 | 1 | 1 | | | | | | | | |
| RJIIT | 1 | 1 | 1_ | 1 | 1 | | | | | | | | |
| RJ14C/W | 2 | 2 | 2 | 2 | 2 | | | | | | | | |
| RJ14X | 2 | 2 | 2 | 2 | 2 | | | | | | | | |
| RJ15C | 1 | 1 | 1 |] | 1 | | | | | | | | |
| RJ17C | 1 | 1 | 1 | 1 | 1 | | | • | | | | | |
| RJ21X | 25 | 25 | 25 | 25 | 25 | | | | | | | | |
| RJ25C | 3 | 3 | 3 | 3 | 3 | | | | | | | | |
| RJICX | | | | | | 1 | 1 |] | 1 | 1 | 1 | | |
| RJ2EX | | | | | | 12 | | | | | | | |
| RJ2FX | | | | | | | 8 | | | | | | |
| RJ2GX | | | | | | | | 8 | | 8 | | | |
| RJ2HX | | | | | | | | | 6 | | 6 | | |
| RJ61X | 4 | 4 | 4 | 4 | 4 | | | | | | | | |

Number indicates the maximum number of circuits per jack.

Table 4. Network Channel Interface Code Structure

Network Channel Interface Code

| Field Identifer | Wi: | tal res See ble | Protocol Codes (See Table 7) | | IMPEDANCE* | DELIMITER | | Protocol Option Codes (See Table 7) | | DELIMITER | TI LEV T R A N S M I T | |
|--------------------|-----|--------------------------|--|---|------------|-----------|---|-------------------------------------|---|-----------|---|----|
| POSITION | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
| CODE | | | | | | | | | | | | |

* See Table 6

Table 5. Network Channel Interface Code Translation - Total Wires

| | Total Wires | | |
|------|-------------|----|-------|
| Code | No. | of | Wires |
| 02 | | 2 | |
| 04 | | 4 | |
| 06 | | 6 | |
| 07 | | 7 | |
| 80 | | 8 | |
| 09 | | 9 | |
| | | | |

Table 6. Network Channel Interface Code Translation - Impedance Codes

| Imp | <u>edance Codes</u> |
|------|---------------------|
| Code | Nominal Z (ohms) |
| 0 | 110 |
| 2 | 600 |
| 3 | 900 |
| 5 | 135 |
| 6 | 75 |
| 9 | 100 |

Table 7. Network Channel Interface Code Translation-Protocol Codes

Note: This list is not all inclusive and is intended to aid in the selection of the proper interface connector.

| Protocol | Impedance/ | |
|--|---|--|
| Code | Protocol Option | Definition |
| AC DA DB | | Provides for the transmission of voice and 20hz ringdown signaling Provides for the transmission of data and/or control supervisory signals Provides for the transmission of data and/or control supervisory signals |
| DC | | Direct current or voltage |
| DE | | Provides for the transmission of data or tones |
| DS | 6 | 44.736 Mb/s Digital Access |
| DU | 5 24 5 24S 5 48 5 48S 5 96 5 96S 5 19 5 19S 5 56 5 56B 5 56S 5 64 7 56B | Digital access interface 2.4 kb/s 2.4 kb/s with secondary channel 4.8 kb/s 4.8 kb/s with secondary channel 9.6 kb/s 9.6 kb/s with secondary channel 19.2 kb/s 19.2 kb/s with secondary channel 56 kb/s Type I or Type III PSDS 56 kb/s with secondary channel 64 kb/s Type II PSDS 1.54 Mb/s |
| EA EB GS LA LB LC LR | | Type I E & M signaling Type II E & M signaling Ground start signaling - closed end function presented by end-user Type A registered port Type B registered port Type C registered port Private Line automatic ringdown with PLAR equipment provided by the LEC Loop start signaling - closed end function presented by the end-user |
| PR | | Provides for voice transmission with no signaling provided by the LEC |
| RV TF | | Provides for transmission of meontrol signals (voice frequency) for protective relaying Reverse battery (trunk signaling at interface) Telephoto interface |

Table 8. Examples of Network Channel Interface Codes (See Table |

| 02LA2 02LB2 02LC2 04EA2-M 04EA2-E 06EA2-M 06EA2-E 06EB2-M 06EB2-E 08EB2-M 08EB2-E | 2-wire Loop 2-wire loop 4-wire Type 4-wire Type 6-wire Type 6-wire Type 6-wire Type 8-wire Type 8-wire Type | signaling - Registered Class A OPS Port signaling - Registered Class B OPS Port signaling - Registered Class C OPS Port I E&M signaling - Battery on M to originat I E&M signaling - Ground on E to originat I E&M signaling - Battery on M to originat I E&M signaling - Ground on E to originat II E&M signaling - Battery on M to originat II E&M signaling - Ground on E to originat II E&M signaling - Ground on E to originat II E&M signaling - Battery on M to originat II E&M signaling - Ground on E to originat II E&M signaling - Ground on E to originat II E&M signaling - Ground on E to originat II E&M signaling - Ground on E to originat |
|---|---|---|
| | 8-wire Type 2-wire Data 4-wire Data | |

| Table 9. | NO | a-Sv | ritc | hed | Ana | log | NCI | /Co | nnec | tor | Mat | TIX | | | | | |
|-------------|--------|--------------------|------|-----|-----|--------|----------|------------|--------|--------|-----|--------|--------|--------|--------|--------|----|
| Jacks | | NCI Protocol Codes | | | | | | | | | | | | | | | |
| | A C | D A | D B | DΩ | DE | E A | EB | G S | L A | L B | ЫC | L R | L S | N O | P R | R V | TF |
| JM8 | | 1 | 1 | | 1 | | | | | | | | | | 1 | | 1 |
| RJ11C /W | 1 | | | 1 | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | 1 | |
| RJ14C /W | 2 | | | 2 | | | | 2 | 2 | 2 | 2 | 2 | 2 | 2 | | 2 | |
| RJ14X | 2 | | | 2 | | | | 2 | 2 | . 2 | 2 | 2 | 2 | 2 | | 2 | |
| RJ15C | 1 | | | 1 | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | 1 | |
| RJ17C | 1 | | | 1 | | | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | | 1 | |
| RJ18C /W | · | | | | | | | | | | | | | | | | |
| RJ1DC | 1 | | | 1 | | | | 1 | | | | 1 | 1 | 1 | | 1 | |
| RJ21X | 25 | | | 25 | | | | 25 | 25 | 25 | 25 | 25 | 25 | 25 | | 25 | |
| RJ25C | 3 | | | 3 | | | | 3 | 3 | 3 | 3 | 3 | 3 | 3 | | 3 | |
| RJ26X | | | | | | | | 8 | | | | | 8 | | | | |
| RJ27X | | | | | | | | 8 | | | | | 8 | | | | |
| RJ1CX | | | | | | 1 | 1 | | | | | | | | | | |
| RJ2DX | 12 | | | 12 | | | | 12 | | | | 12 | 12 | 12 | | 12 | |
| RJ2EX | | | | | | 12 | | | | | | | | | | | |
| RJ2FX | | | | | | | 8 | | | | | | | | | | |
| RJ2GX | | | | | | 8 | | | | | | | | | | | |
| RJ2HX | | | | - | | | 6 | | | | | | | | | | |
| RJ2MB | | | | | | | | | | | | | | | | | |
| RJ41S | | | | | | | | 1 | | | | | 1 | | | | |
| RJ45S | | | | | | | <u> </u> | 1 | | | | | 1 | | | | |
| RJ4MB | | | | | | | | | | | | | | | | | |
| RJ61X | 4 | | | 4 | | | | 4 | 4 | 4 | 4 | 4 | 4 | 4 | | 4 | |
| JM25X | | 8 | 8 | | 8 | | | | | | | | | | 8 | | 8 |

The number indicates the maximum number of circuits per jack

Table 10. Non-Switched Digital NCI/Connector Matrix *

| Jacks | NCI Protocol Codes | | | | | | | | | | | | |
|-------|---------------------------------|---------------|-----------|-----------|-----------|-----------|-------------|--------|-------------|----------|----------|-----|---------|
| | D U 5 - 2 4 S | D D 5 - 4 8 S | DD5 - 965 | DD5 - 198 | AD5 1 565 | D D 5 2 4 | D U 5 - 4 8 | DD5-96 | D U 5 - 1 9 | DD5 - 56 | DD5 - 64 | 000 | DU 9 |
| RJ48C | | | | | | | | | | | | | 1 |
| RJ48H | | | | | | | | | | | | | 12 |
| RJ48M | | | | | | | | | | | | | 8 |
| RJ48S | | | | | | 1 | 1 | 1 | | 1 | | | |
| RJ48T | | | | | | 12 | 12 | 12 | | 12 | | | |
| RJ48X | | | | | | | | | | | | | 1 |
| SJA44 | · | | | | | | | | | | | 1 | |
| SJA56 | 1 | 1 | 1 | 1 | 1 | | | | 1 | | 1 | | |
| SJA57 | 12 | 12 | 12 | 12 | 12 | | | | 12 | | 12 | | |

The number indicates the maximum number of circuits per ja

^{*} Note: Primary Rate ISDN services utilize the same connected as listed for the DU 9 NCI Protocol Code.

Table 11. Switched Analog Matrix

| Jacks | | | 1 Li | ine | | 2 L i n e | 3 L i n e | 4 L i n e | Multiple Lines | | | |
|-------------|---|--------|-------------|------------|---|-----------------------|-----------------------|-----------------------|-------------------|-------------|------------|---|
| | | M B | Pro Data | Pro FLL | | | | | M B | Pro Data | Pro FLL | |
| RJ11 C/W | 1 | | | | | | | | | | | |
| RJ14 C/W | | | | | | 2 | | | 2 | | | |
| RJ14X | | | | | | 2 | | | 2 | | | |
| RJ15C | 1 | | | | | | | ŕ | | | | |
| RJ17C | 1 | | | | | | | | | | | |
| RJ18 C/W | 1 | 1 | | | | | | | | | | l |
| RJ21X | | | | | | | | | 25 | | | |
| RJ25C | | | | | | | 3 | | 3 | | | |
| RJ26X | | | | | | | | | 8 | | | 8 |
| RJ27X | | | | | | | | | 8 | | 8 | |
| RJ2MB | | | | | | | | | 12 | 12 | | |
| RJ41S | | | | | 1 | | | | | | | |
| RJ45S | | | 1 | | | | | | | | | |
| RJ4MB | | | | 1 | | | | | | | | |
| RJ61X | | | | | | | | 4 | 4 | | | |

Number indicates the maximum number of circuits per jack MB = Make Busy

Pro Data = Programmable Data

MB Pro = Combined Make Busy and Programmable Data
Pro FLL = Combined Programmable Data and Fixed Loss Loop

Table 12. Switched Digital Matrix *

| Jacks | ISDN Basic Access | PSDS 2-Wire | PSDS 4-Wire Single | PSDS 4-Wire Multiple |
|-------|-------------------------|----------------|--------------------------|----------------------------|
| RJ48S | | | 1 | |
| RJ48T | | | | 12 |
| RJ11C | 1 | 1 | | |
| RJ21X | 25 | 25 | | |
| RJ49C | 1 | | | |

Number indicates the maximum number of circuits per jack

ISDN = Integrated Services Digital Network

PSDS = Public Switched Digital Service

Note: ISDN Primary rate connectors are the same connectors used for DS 1 services. See Table 9.

5. CARRIER/CI INTERFACE CONNECTOR WIRING CONFIGURATIONS

| | | | ISSUE |
|------------|---------------|-----------|----------------|
| PAGE | <u>FIGURE</u> | CONNECTOR | DATE |
| 23 | 5.1 | RJ11C/W | June, 1996 |
| 23A | 5.1.1 | RJ11T | June, 1990 |
| 24 | 5.2 | RJ14C/W | n |
| 25 | 5.3 | RJ14X | 11 |
| 26 | 5.4 | RJ15C | n |
| 27 | 5.5 | RJ17C | " |
| 28 | 5.6 | RJ18C/W | n |
| 29 | 5.7 | RJ21X | n |
| 30 | 5.8 | RJ25C | " |
| 31 | 5.9 | RJ26X | n |
| 32 | 5.10 | RJ27X | 97 |
| 33 | 5.11 | RJ41S | 11 |
| 34 | 5.12 | RJ45S | n . |
| 35 | 5.13 | RJ61X | 'n |
| 36 | 5.14 | RJ2MB | 17 |
| 37 | 5.15 | RJ4MB | n |
| 38 | 5.16 | RJ1DC | 21 |
| 39 | 5.17 | RJ2DX | Ħ |
| 40 | 5.18 | RJ2EX | n |
| 41 | 5.19 | RJ2FX | , |
| 42 | 5.20 | RJ2GX | n |
| 43 | 5.21 | RJ2HX | н |
| 44 | 5.22 | JM8 | n |
| 45 | 5.23 | RJXCX | November, 1990 |
| 48 | 5.26 | SJA56 | June, 1996 |
| 49 | 5.27 | SJA57 | 19 |
| 50 | 5.28 | RJ48C | June, 1990 |
| 51 | 5.29 | RJ48X | 'n |
| 52 | 5.30 | RJ48M | n |
| 53 | 5.31 | RJ48H | н |
| 54 | 5.32 | RJ48S | June, 1996 |
| 5 5 | 5.33 | RJ48T | Ħ |
| 55A | 5.33.1 | RJ49C | n |
| 56 | 5.34 | SJA44 | June, 1990 |
| 57 | 5.35 | JM25X | December, 1993 |
| 58 | 5.36 | SJASC | n |
| | | | |

RJ11C/W

ELECTRICAL NETWORK CONNECTION:

SINGLE LINE TIP AND RING: RJ11W FOR W

MOUNTINGS AND RJ11C FOR ALL OTHERS

MECHANICAL ARRANGEMENT:

6 POSITION MINIATURE MODULAR JACK

USAGE:

SINGLE EXCHANGE ACCESS LINE

INTERFACE CODES:


OL13A; OL13B; OL13C; AX15X; MX13X;

METALLIC 2W; 02LA2; 02LB2; 02LC2; O2LS2 02GS2; 02RV2-T; 02LR2; 02AC2; 02NO3; 02D1

56B

WIRING DIAGRAM:

02DU7-56B



5.1.1 RJ11T June 1996

UNIVERSAL SERVICE ORDER CODE (USOC):

RJIIT

ELECTRICAL NETWORK CONNECTION:

SINGLE LINE TIP AND RING

MECHANICAL ARRANGEMENT:

6 POSITION MINIATURE MODULAR JACK

(SPECIAL)

USAGE:


SINGLE EXCHANGE ACCESS LINE

INTERFACE CODES:

OL13A; OL13B; OL13C; AX15X; MX13X;

METALLIC 2W; 02LA2; 02LB2; 02LC2; O2LS2; 02GS2; 02RV2-T; 02LR2; 02AC2; 02NO2;

WIRING DIAGRAM:



Application note: This connector is different than the RJ11C/W in that customer wiring is connected to the network without the use of a plug. When a plug is inserted into the RJ11T, customer wiring and CPE on the same line will be disconnected.

RJ14C/W

ELECTRICAL NETWORK CONNECTION:

TWO LINE TIP AND RING: RJ14W FOR WALL MOUNTINGS AND RJ14C

FOR ALL OTHERS

MECHANICAL ARRANGEMENT:

6 POSITION MINIATURE MODULAR


JACK

USAGE:

TWO EXCHANGE ACCESS LINES

INTERFACE CODES:

OL13A; OL13B; OL13C; AX15X; MX13X; METALLIC 2W; 02LS2; 02GS2; 02RV2-T; 02LR2; 02AC2; 02NO2; 02LA2; 02LB2; 02LC2



RJ14X

ELECTRICAL NETWORK CONNECTION:

TWO LINE TIP AND RING

MECHANICAL ARRANGEMENT:

6 POSITION MINIATURE MODULAR JACK WITH A SLIDING COVER TO FACILITATE TESTING OF EACH LINE

USAGE:


TWO EXCHANGE ACCESS LINES WITH THE PROVISION FOR TESTING EACH LINE WITH A STANDARD SINGLE LINE TELEPHONE.

INTERFACE CODES:

OL13A; OL13B; OL13C; AX15X; MX13X; METALLIC 2W; 02LA2; 02LB2; 02LC2;

02LS2; 02GS2; 02RV2-T; 02LR2; 02AC2; 02NO2

WIRING DIAGRAM:



NOTE; THE EXCHANGE CARRIER WILL WIRE THE LINES TO THE CONNECTOR IN THE SEQUENCE DESIGNATED BY THE CUSTOMER.

RJ15C

ELECTRICAL NETWORK CONNECTION:

SINGLE LINE TIP AND RING

MECHANICAL ARRANGEMENT:

3 POSITION WEATHERPROOF

JACK

USAGE:


SINGLE EXCHANGE ACCESS LINE

IN MARINAS

INTERFACE CODES:

OL13A; OL13B; OL13C; AX15X; MX13X; METALLIC 2W; O2LS2; 02GS2; 02RV2-T;

02LR2; 02AC2; 02NO2



RJ17C

ELECTRICAL NETWORK CONNECTION:

SINGLE LINE TIP AND RING; POSITIONS

2,3,4,& 5 ARE NOT EQUIPPED WITH

CONTACTS

MECHANICAL ARRANGEMENT:

6 POSITION MINIATURE MODULAR JACK FOR TERMINAL EQUIPMENT WHICH COMPLIES WITH 1978 NEC,

ARTICLE 517.

USAGE:

SINGLE EXCHANGE ACCESS LINE IN HOSPITAL CRITICAL CARE AREAS. USE IS RESTRICTED TO CONNECTION OF DEVICES WHICH COMPLY WITH ARTICLE 517 OF THE 1978 NATIONAL ELECTRICAL


CODE.

INTERFACE CODES:

OL13A; OL13B; OL13C; AX15X; MX13X; METALLIC 2W; 02LA2; 02LB2; 02LC2

02LS2; 02GS2; 02RV2-T; 02LR2;

02AC2; 02NO2



RJ18C/W

ELECTRICAL NETWORK CONNECTION:

SINGLE LINE TIP AND RING WITH

MB/MB1 LEADS

MECHANICAL ARRANGEMENT:

6 POSITION MINIATURE MODULAR

JACK; T/R WITH MAKE BUSY

ARRANGEMENT


USAGE:

SINGLE EXCHANGE ACCESS LINE

WITH A MAKE BUSY

INTERFACE CODES:

02LS2: 02GS2; 02RV2-T



RJ21X

ELECTRICAL NETWORK CONNECTION:

UP TO 25 TIP/RING CONNECTIONS

MECHANICAL ARRANGEMENT:

50 POSITION MINIATURE RIBBON

JACK: 25 T&R

USAGE:

MULTIPLE EXCHANGE ACCESS LINES


INTERFACE CODES:

OL13A; OL13B; OL13C; AX15X; MX13X; METALLIC 2W; O2LA2; O2LB2; O2LC2;

02LS2; 02GS2; 02RV2-T; 02LR2;

02AC2; 02NO2

WIRING DIAGRAM:



NOTE; THE EXCHANGE CARRIER WILL WIRE THE LINES TO THE CONNECTOR IN THE SEQUENCE DESIGNATED BY THE CUSTOMER.

RJ25C

ELECTRICAL NETWORK CONNECTION:

UP TO THREE LINES, TIP AND RING

MECHANICAL ARRANGEMENT:

6 POSITION MINIATURE MODULAR

JACK

USAGE:

THREE EXCHANGE ACCESS LINES


INTERFACE CODES:

OL13A; OL13B; OL13C; AX15X; MX13X; METALLIC 2W; O2LA2; O2LB2; O2LC2;

02LS2; 02GS2; 02RV2-T; 02LR2;

02AC2; 02NO2

WIRING DIAGRAM:



NOTE; THE EXCHANGE CARRIER WILL WIRE THE LINES TO THE CONNECTOR IN THE SEQUENCE DESIGNATED BY THE CUSTOMER.